DRIFTER GPC SETUP PROCEDURE

This procedure outlines a protocol for configuring the FOX D27 GPC on the Drifter platform for normal use.

https://www.acmesystems.it/doc_foxd27

- 1. Copy the image from a working image.
 - a. sudo dd if=/dev/sdb of=/home/eric/Desktop/fox card.img bs=4M status=progress
 - b. sudo dd if=/home/eric/Desktop/fox_card.img of=/dev/sdb bs=4M status=progress
- 2. Plug in TTL UART into serial console port header. 115200, 8,N,1
- 3. Set shutdown switch to 5V and plug in USB port to power board.
- 4. Login is user: acme/Password: acmesystems
- 5. repartition to fill card
 - a. sudo fdisk -l
 - b. sudo fdisk -l /dev/mmcblk0
 - c. sudo apt update
 - d. sudo apt install parted
 - e. sudo parted /dev/mmcblk0
 - i. (parted) resizepart 2
 - 1. 100%
 - ii. 'q' to quit
 - f. resize the filesystem
 - i. sudo resize2fs /dev/mmcblk0p2
 - g. sudo reboot
- 6. Install python
 - a. sudo apt update
 - b. sudo apt install python3-libgpiod
- 7. Set a fixed IP address
 - a. edit /etc/network/interfaces.d/eth0 with "sudo nano /etc/network/interfaces.d/eth0
 - b. Comment out the code that's there with '#' on the first four lines.
 - c. Add the following code:

auto eth0

iface eth0 inet static

address 192.168.9.1 netmask 255.255.255.0

TICHTIGSK 200:200:200:

gateway 192.168.9.90

- d. reboot by running 'sudo halt' and pulling power once shut down followed by repowering.
- e. verify ip address is 192.168.9.1 with 'sudo ifconfig'
 - i. Note sometimes I set to 192.168.8.207 (default gateway 192.168.8.1) to get on internet and be on the same subnet as the computer.
- 8. Set up an ssr account
 - a. sudo adduser ssr
 - b. sudu passwd ssr (set to Jameswebb18-)

- c. sudo usermod -a -G sudo,users ssr
- d. sudo halt and log back in as ssr
- 9. Install Samba
 - a. mkdir Share
 - b. sudo apt update
 - c. sudo apt upgrade
 - d. sudo apt install samba
 - e. whereis samba (check if successful) should output samba: /usr/sbin/samba
 - . Create a directory that samba will point to eg. sudo mkdir /home/ssr/Share
 - f. edit configuration file in /etc/samba/smb.conf with "sudo nano /etc/samba/smb.conf"
 - g. Add the following at the beginning of the file after [global][global]

```
oplocks = no
level2 oplocks = no
```

```
[sambashare]
  comment = Samba on Ubuntu
  path = /home/username/sambashare
  read only = no
  browsable = yes
```

[sambashare]

comment = Samba on Ubuntu path = /home/ssr/Share read only = no browsable = yes oplocks = no level2 oplocks = no

- h. restart samba for configuration to take effect "sudo service smbd restart"
- i. UPdate firewall rules to allow samba traffic "sudo ufw allow samba" (probably don't need this'
- j. give read write access to all users for the mapped directory using chmod 777 eg. "sudo chmod 777 /home/ssr/Share"
- k. set the samba username and password to the system account "sudo smbpasswd -a ssr"
- I. reboot with 'sudo halt' and pull power and restart
- m. Test Samba
 - i. With an ethernet cable connect a laptop
 - ii. Disable WiFi
 - iii. On Laptop Configure ethernet settings IPV4

- 1. Use Following
 - a. IP Address 192.168.9.9
 - b. Subnet Mask: 255.255.255.0
 - c. Default Gateway: 192.168.9.90
- iv. In Putty connect to 192.168.9.1 (Default Drifter IP address) or in linux ssh ssr@192.168.9.1
- v. Map Network Drive \\192.168.9.1\sambashare
- 10. Install libgpiod
 - a. "sudo apt update"
 - b. "sudo apt install python3-libgpiod"
- 11. Install minicom
 - a. sudo apt update
 - b. sudo apt install -y minicom
 - c. sudo minicom -s
- 12. Reconfigure the Device Tree
- 13. Install the Arm Crossplatform Toolchain ON A PC with UBUNTU or in VirtualBox
 - a. sudo apt update
 - b. sudo apt install libc6-armel-cross libc6-dev-armel-cross binutils-arm-linux-gnueabi libncurses5-dev build-essential bison flex libssl-dev bc
 - c. sudo apt install gcc-arm-linux-gnueabihf g++-arm-linux-gnueabihf
 - d. Install SSH client to allow copying files to board
 - i. sudo apt update
 - ii. sudo apt install openssh-client
 - iii. Test connection with sudo ssh ssr@192.168.8.217
 - iv. 'exit' to close ssh
 - 1. to copy files to the linux device via ssh use
 - a. scp hello ssr@[your_board_ip]:/home/ssr/hello
 - e. Install the kernel resources
 - i. wget https://www.kernel.org/pub/linux/kernel/v4.x/linux-4.19.134.tar.xz
 - ii. tar xvfJ linux-4.19.134.tar.xz
 - iii. cd linux-4.19.134
 - f. Install git
 - i. sudo apt update
 - ii. sudo apt install git
 - g. Install a local git repository for acme files
 - i. git init; git add .; git commit -m "Linux vanilla"; git branch acme; git checkout acme
 - ii. If git credentials not set up set them up (eg. eberkenpas...)
 - iii. wget
 https://raw.githubusercontent.com/AcmeSystems/acmepatches/master/linux-4.19.x.patch
 - iv. patch -p1 < linux-4.19.x.patch
 - h. make ARCH=arm CROSS_COMPILE=arm-linux-gnueabihf-acme-roadrunner-10uart.dtb

- i. copy acme-roadrunner-10uart.dtb to /boot/ directory on the FOX D27
 - i. scp acme-roadrunner-10uart.dtb:/boot/acme-roadrunner-10uart.dtb
- j. backup acme-roadrunner.dtb on the Roadrunner platform
 - i. ssh ssr@192.168.8.217
 - ii. cd/boot
 - iii. sudo cp acme-roadrunner.dtb acme-roadrunner-original.dtb
- k. overwrite acme-roadrunner.dtb with the new one
 - i. sudo cp acme-roadrunner-10uart.dtb acme-roadrunner.dtb
- I. reboot platform
 - i. sudo reboot
- m. log back into platform
- 14. Check comms with drifter controller
 - a. sudo minicom -o -b 57600 -D /dev/ttyS2
- 15. Install serial python libraries
 - a. Download pyserial
 - i. curl -0

https://files.pythonhosted.org/packages/1e/7d/ae3f0a63f41e4d2f6cb66a5b57197850f919f59e558159a4dd3a818f5082/pyserial-3.5.tar.gz

- ii. tar -xzf pyserial-3.5.tar.gz
- iii. cd pyserial-3.5
- iv. sudo python3 setup.py install
- v. Check version python3
 - 1. import serial
 - 2. serial.VERSION
- vi. install GPIOD library for GPIOS
 - 1. sudo apt update
 - 2. sudo apt install python3-libgpiod
- b. Add current user to dialout to give serial permission
 - i. sudo usermod -a -G dialout \$USER
 - ii. reboot for new settings to take effect
 - 1. sudo reboot
- 16. Make ssr a root user that doesn't need to enter a password for a sudo call
 - a. sudo visudo
 - b. Add the following to the last line:
 - i. ssr ALL=(ALL) NOPASSWD: ALL
 - c. Check if settings are good by using:
 - i. sudo -u ssr sudo whoami
- 17. Configure GPCstart.py to run on boot.
 - a. copy the 'gpc_start.service' file to the /etc/systemd/system/ folder
 - i. go to the driftersystem folder
 - ii. sudo cp gpc_start.service /etc/systemd/system/gpc_start.service
 - b. Enable and Start the service
 - i. Reload the systemd manager to recognize the new service
 - 1. sudo systemctl daemon-reload

- ii. Enable the service so that it starts on boot
 - 1. sudo systemctl enable gpc_start.service
 - 2. sudo systemctl disable gpc_start.service (to disable)
- iii. Start the service to immediately test it
 - 1. sudo systemctl start gpc_start.service
 - 2. sudo systemctl stop gpc_start.service
- iv. Check the status of your service to verify it is actively running
 - 1. sudo systemctl status gpc_start.service
- 18. Create the "Data" folder to save all data files.
 - a. cd/home/ssr/Share
 - b. sudo mkdir Data
 - c. sudo chmod -R 777 /home/ssr/Share/Data
- 19. Configure "drifterterm" for execution (allows user to enter terminal mode on the drifter controller.
 - a. Go to driftersystem directory
 - i. cd /home/ssr/Share/driftersystem
 - b. Make the drifterterm file executable
 - i. sudo chmod +x drifterterm
 - c. Copy this file to /usr/local/bin
- 20. Configure downloadDataScript bash file be executable and copy to the same folder.

Pinout FOX Board D27





