

# DRIFTER GPSP BULKHEADS



# T2 USBL



#### Bulkhead Connections Drifter Breakout Board Connections

1: Black U1TX (USBL Pin 5)
2: White U1RX (USBL Pin 4)

3: Red N/C

4: Green GND (USBL Pin 2)

5: Orange +14V (USBL Pin1)


6: Blue N/C 7: White/black N/C

8: Red/black\* N/C

9: Green/black N/C

10: Orange/black\*\* N/C

# T3 RELEASE/JTAG



Bulkhead Connections Drifter Breakout Board Connections

1: Black NO-CONNECTION - 6

2: White PGC-53: Red PGD-4

4: Green VSS (GND) -3

5: Orange VDD (TARGET VOLTAGE) -2

6: Blue MCLR-1


7: White/black +V\_RELEASE

8: Red/black\* GND
9: Green/black N/C

10: Orange/black\*\* N/C

### **T4 SENSOR PAYLOAD 1**

Electrically Connected to T6 pins



Bulkhead Connections Drifter Breakout Board Connections

1: Black GPC UART2 TX
2: White GPC UART2 RX
3: Red GPC UART4 TX

4: Green GND

5: Orange GPC UART4 RX
6: Blue V Payload 1 (12V)


7: White/black V Payload 2 (12V)

8: Red/black\* GND 9: Green/black GND

10: Orange/black\*\* N/C

### T4 SENSOR PAYLOAD 2

Electrically Connected to T4 pins




#### Bulkhead Connections Drifter Breakout Board Connections

1: Black	GPC UART2 TX
2: White	GPC UART2 R
3: Red	GPC UART4 TX
4: Green	GND
5: Orange	GPC UART4 RX

5: Orange GPC UART4 RX
6: Blue V Payload 1 (12V)
7: White/black V Payload 2 (12V)

8: Red/black\* GND
9: Green/black GND
10: Orange/black\*\* N/C


## T7 UMBILLICAL



#### Inline cable colour code Drifter Breakout J1 Umbillical Header

1: Black	GND1
2: White	GND2
3: Red	+VBATT_EXT1
4: Green	+VBATT_EXT2
5: Orange	VPP_CS1
6: Blue	VPP_CS2
7: White/black	AUX0
8: Red/black	AUX1
9: Green/black	AUX2

# T8 CHARGE PROG



#### Inline cable colour code Charge Prog Header

1: Black GND1
2: White GND2
3: Red +VBATT1
4: Green +VBATT2
5: Orange BATTERY\_SPLIT1
6: Blue CABLE\_DETECT
7: White/black U2TX\_PROG


U2RX PROG

VPP

8: Red/black

9: Green/black

# T9 ETHERNET



#### Face view (male)



#### Inline cable colour code

1-2: Brown, Brown/white\*

3-4: Blue, Blue/white\*

5-6: Orange, Orange/white\*

7-8: Green, Green/white\*

9: Screen (orange wire on bulkhead)